



Quantitative, In-clinic Results with a High Throughput

Phone - 800.233.0210

BIONOTE

Affordable, rapid and proven, Vcheck is the only in-clinic immunofluorescence assay analyzer that captures 12 biomarkers, including Canine NT-proBNP, for the detection of heart disease in just one visit. Vcheck improves patient care by delivering actual quantitative results in minutes, eliminating estimates, ambiguity and the need for reference lab confirmation. Vcheck's V2400 analyzer is an in-clinic, multiple-test analyzer with high throughput for large hospitals and laboratories to complement your point-of-care lab for time-saving diagnosis and faster initiation of treatment plans.

Precise quantitative result

No positives, negatives or estimates

Significant cost savings per test The most affordable analyzer available

Easy user interface Optical Character Recognition (OCR) reads handwriting directly from test

Auto-coding system with 2D barcode technology Randomly accessible without any pre-procedure

Compact yet well-suited to larger clinics and laboratories

Up to 70 tests per hour, 24 tests at once



www.pennvet.com

Available Test Reagents

Cardiac

Detection and monitoring of heart disease in dogs and cats, including MMVD and DCM

- Canine NT-proBNP
- Canine Tnl

Acute Inflammation

Earlier detection of acute inflammation in dogs and cats Canine CRP Feline SAA

Pancreatitis

Definite diagnosis of Pancreatitis in dogs and cats

• cPL (canine Pancreasspecific Lipase)

• fPL (feline Pancreasspecific Lipase)

Canine TSH

Feline NT-proBNP

Coagulation

Highly sensitive marker for thromboembolism

Canine D-dimer

Hormones

A hormone marker for Cushing's and Addison's diseases

Canine Cortisol

A hormone marker for diagnosis of thyroid gland diseases

• T4 (Thyroxine)

For determining optimal breeding dates

Canine Progesterone

Specifications

Vcheck V2400		
24 tests at once / 70 tests per hour		
AC/DC adaptor 120V		
10" Color Touch Screen		
Built-in		
HL7 v2.6(PCD-01) / POCT1-A		
20.0" Wide x 22.0" Deep x 11.6" High		
40.0 lbs		

Simple Testing Procedure



1. Dilute the

sample



diluted ple into a test device

3. Check the test result

2.Add
samp

Product Name	Product Number	Product Type	Packing Unit
Vcheck Canine NT-pro BNP	VCF132DC	Device	5 Tests/Kit
Vcheck Feline NT-pro BNP	VCF130DC	Device	5 Tests/Kit
Vcheck Canine CRP 2.0	VCF109DD	Device	10 Tests/Kit
Vcheck Feline SAA 2.0	VCF128DD	Device	10 Tests/Kit
Vcheck cPL 2.0	VCF129DD	Device	10 Tests/Kit
Vcheck fPL 2.0	VCF127DD	Device	10 Tests/Kit
Vcheck D-dimer	VCF107DD	Device	10 Tests/Kit
Vcheck cCortisol	VCF105DD	Device	10 Tests/Kit
Vcheck T4	VCF106DD	Device	10 Tests/Kit
Vcheck Canine TSH	VCF118DC	Device	5 Tests/Kit
Vcheck cProgesterone	VCF122DD	Device	10 Tests/Kit
Vcheck Canine Tnl	VCF137DC	Device	5 Tests/Kit



For More Information: bionote.com customerservice@bionote.com 800-727-5169

More From Bionote Vcheck V200

Lightweight, small footprint Complements any clinic lab

